

### SAFE GRIP

A specially formulated liquid designed to improve the slip resistance of hard porous surfaces that become slippery when moist or wet.

### WHERE TO USE

Safe Grip can be used on Ceramic, Marble, Terracotta and Terrazzo tiles; traditional Terrazzo floors, granite, stone, concrete and similar types of materials. Also suitable for enamel/porcelain baths and shower trays.

**Safe Grip SHOULD NOT** be applied to plastic, wood, acrylic, epoxy, polyurethane, vinyl, linoleum, glass and similar types of products.

If in doubt please consult the company for advice before applying the product.

### PHYSICAL PROPERTIES

**Pack Sizes:** 5 Litre, 2.5 Litre, 1 litre, 500ml & 250ml

**Coverage:** Varies according to the type of surface and profile of surface, typically 15m<sup>2</sup>/litre

### Application and Storage

Temperature Limits.  
Recommended 5°C to 30°C

### SAFETY & HYGIENE

Safe Grip is a low odour product and is completely solvent free.

At all times applicators should wear appropriate safety clothing and maintain good standards of hygiene.

Further safety information may be obtained from Material Safety Data Sheet Ref: SDS – SG1.

### PREPARATION

Surfaces on which the application is to be made should be clean; ensure there are no dirt or grease deposits present on the surface by initially washing the floor with a good quality emulsifying cleaning agent suitable for hard surfaces; we recommend our **Safe Kleen Multi Purpose Cleaner**. Thoroughly rinse and remove all soiled water.

### APPLICATION

Prior to any application of Safe Grip we recommend a small test is carried out in an inconspicuous area to determine the suitability of the treatment. This test will also assist in establishing the exposure time required.

Do not apply Safe Grip in high temperatures or on hot surfaces to avoid premature drying before the product has activated.

A: The surface to receive the treatment should preferably be dry but may be a little damp. However, the surface must be free of standing water.

B: Spread the **Safe Grip** liberally and evenly using a brush, mop or sponge and allow to stand for the selected period of time. Agitate periodically during the activation period.

C: At the end of the treatment period rinse off with clean water, the area is now ready for immediate use.

**Please refer to Full application instructions (as supplied with product) before commencing application.**

### GENERAL INFORMATION

The information contained in this description sheet is, to the best of our knowledge, correct and reliable.

Anti Slip Solutions Ltd endeavours to ensure that any recommendations, advice or specification assistance is, to the best of the company's ability, accurate and correct but due to the fact we have no direct control over where or how the material is applied cannot accept any liability, either directly or indirectly, for the use of this product.

In the event of the product being found faulty due to a manufacturing defect, within 12 months from the date of purchase, the company will supply replacement material on a free of charge basis.

**Anti Slip Solutions Ltd**  
Beauchamp House  
402/403 Stourport Road  
Kidderminster Worcs  
DY11 7BG UK  
Tel +44 (0) 345 222 5613

e mail: info@safe-grip.co.uk  
www.safe-grip.co.uk